


## Beteckningar



## Teknisk data

| Modell | Drift | Märkspänning<br>[V] | Hastighet<br>[r.p.m.] | P max<br>[W] | I max<br>[A] | Q max<br>[m <sup>3</sup> /h] | P<br>statiskt [Pa] | LWA<br>[db(A)] | Vikt<br>[kg] | Temp.<br>min.<br>[°C] | Temp.<br>max.<br>[°C] |
|--------|-------|---------------------|-----------------------|--------------|--------------|------------------------------|--------------------|----------------|--------------|-----------------------|-----------------------|
|--------|-------|---------------------|-----------------------|--------------|--------------|------------------------------|--------------------|----------------|--------------|-----------------------|-----------------------|

## Dimensioner (mått i millimeter)

### VENTUR tekniska ab, Göteborg

Manufakturvägen 7A  
SE-417 07 Göteborg, Sweden

Tel. +46 31-23 50 80  
fax +46 31-23 87 98

e-mail: info@ventur.se

### VENTUR tekniska ab, Stockholm

Västberga Allé 1A  
SE 126 30 HÄGERSTEN, Sweden

Tel. +46 8-534 101 90  
fax +46 8-534 101 99

e-mail: info@ventur.se