



## Beteckningar

## Teknisk data

Modell	Drift	Märkspänning [V]	Hastighet [r.p.m.]	P max [W]	I max [A]	Q max [m <sup>3</sup> /h]	P statistiskt [Pa]	Temp. min. [°C]	Temp. max. [°C]
LBB-4-315S		230	1400	120	0.56	1300	310	-15	60
LBB-6-315S		230	965	37	0.18	800	120	-15	60
LBB-4-355S		230	1400	230	1.2	2300	410	-15	60
LBB-6-355S		230	875	70	0.33	1400	160	-15	60
LBB-4-400S		230	1415	370	1.64	3050	510	-15	70
LBB-4-400T	D	400	1415	320	1	3050	510	-15	70
LBB-6-400S		230	950	150	0.7	2100	225	-15	70
LBB-6-400T	D	400	950	120	0.4	2100	225	-15	70
LBB-4-450S		230	1350	540	2.4	4000	715	-15	70
LBB-4-450T	D	400	1215	650	1.2	3600	575	-15	50
LBB-6-450S		230	850	260	1.2	2500	290	-15	70
LBB-6-450T	D	400	875	265	0.65	2500	290	-15	50
LBB-4-500S		230	1340	1050	4.7	6400	700	-15	55
LBB-4-500T	D	400	1350	1100	1.91	6400	700	-15	70
LBB-6-500S		230	815	320	1.4	4000	280	-15	60
LBB-6-500T	D	400	860	360	0.75	4000	280	-15	60
LBB-4-560T	D	400	1240	1700	3	8000	740	-15	50
LBB-6-560S		230	860	585	2.7	5500	350	-15	55
LBB-6-560T	D	400	860	500	1.1	5500	350	-15	70
LBB-4-630T	D	400	1300	3550	5.9	11000	880	-15	45
LBB-6-630T	D	400	875	960	1.9	7500	400	-15	70
LBB-6-710T	D	400	927	2200	5	13000	800	-15	60
LBB-8-710T	D	400	630	910	2.2	9000	270	-15	50
LBB-4-315T	Y	400	1400	100	0.48	1300	310	-15	60
LBB-4-355T	Y	400	1400	200	1.1	2300	410	-15	60
LBB-4-400T	Y	400	1065	235	0.7	2300	290	-15	70
LBB-6-400T	Y	400	690	105	0.3	1500	120	-15	70
LBB-4-450T	Y	400	860	370	0.64	2500	290	-15	50
LBB-6-450T	Y	400	690	165	0.3	2000	190	-15	50
LBB-4-500T	Y	400	1055	770	1.25	5000	420	-15	70
LBB-6-500T	Y	400	660	225	0.4	3050	170	-15	60
LBB-4-560T	Y	400	882	920	1.8	5500	350	-15	50

Modell	Drift	Märkspänning [V]	Hastighet [r.p.m.]	P max [W]	I max [A]	Q max [m <sup>3</sup> /h]	P statiskt [Pa]	Temp. min. [°C]	Temp. max. [°C]
LBB-6-560T	Y	400	640	335	0.6	4000	200	-15	70
LBB-4-630T	Y	400	1015	2200	3.6	4000	540	-15	45
LBB-6-630T	Y	400	685	640	1.2	6000	240	-15	70
LBB-6-710T	Y	400	802	1700	2.9	11000	440	-15	60
LBB-8-710T	Y	400	465	510	1	6500	150	-15	50

## Dimensioner (mått i millimeter)

### VENTUR tekniska ab, Göteborg

Manufakturgatan 7A  
SE-417 07 Göteborg, Sweden

Tel. +46 31-23 50 80  
fax +46 31-23 87 98

e-mail: [info@ventur.se](mailto:info@ventur.se)

### VENTUR tekniska ab, Stockholm

Västberga Allé 1A  
SE 126 30 HÄGERSTEN, Sweden

Tel. +46 8-534 101 90  
fax +46 8-534 101 99

e-mail: [info@ventur.se](mailto:info@ventur.se)